

The ErgoMatic

Step 27-30: Creating & Attaching the Tech Pocket Wall

First- Let's attach the Tech Walls!

Steps 27-29



Step 27



Step 27— Here's a closer view of the pressed over zipper/Wall top area as well as the bias taping.

And below— the Tech Wall is fully attached and now let's attach the Tech Pocket itself. (on page 2)





The ErgoMatic

Step 27-30: Creating & Attaching the Tech Pocket Wall (cont.)



ALL of these pictures are in support of step 30.

