

the Gemini FlightBag

Step 40: Attaching Thin Panel Unit to Bag Front

Zipper mark



40) Retrieve Bag Front from step 13. Place it LSD on flat surface then place the “zippered” side edges of Thin Panel unit EST with Bag Front aligning all notches & edges while centering zipper mark over quadruple notch.



I recommend clipping into the Thin Panel side edges just short of the stay-stitching at the two bottom curves of Bag Front ONLY to help ease them in place. (see picture below)

(Do NOT clip into zipper tape edges!)

Using a zipperfoot, stitch 1/4” from edges around entire circumference of Bag Front. Restitch for security.

Tip Box– *this stitching is best done w/LS of Bag Front face DOWN on machine bed. Please be advised that out of necessity, Fig.41 indicates Bag Front Face UP. DO check the underside of your stitching area occasionally to make sure loose bias tape folds stay clear of this stitching.*

