



the Gemini FlightBag

Step 43: Attaching Bag Front to Center Wall



43) Push bias-taped seam INWARD so Bag Front is completely RSO. (Retrieve Center Wall unit from step 19 & place it "zippered-side DOWN. Now place Bag Front LST on "UNzippered-side" of Center Wall unit (ES of Bag Front should be facing UP).



Clip to stay-stitching of Thin Panel edges at all four Bag corners to ease them in place.



Stitch a scant 1/4" from edges with "zippered" side of Center Wall face DOWN on machine bed.



the Gemini FlightBag (page 2)

Step 43: Attaching Bag Front to Center Wall



Stitch in place with Center Wall face DOWN on machine bed (as shown at left)



Here's how the flip side, (the Center Wall) should look after being sewn in place.

This is the side you'll be initially applying your bias tape to.