

the Gemini FlightBag

Step 44: Attaching Wide Panel Unit to Center Wall



44) Retrieve Wide Panel Unit from step 32 & turn it LSO.

IMPORTANT!!! In order to keep your finished bag balanced, it is imperative that you place the D-ringed/tabbed edge of your Wide Panel unit **DOWN** as shown & "first in" as you align it with the edges & notches of the Thin Panel unit, or your finished Bag will **NOT** function correctly!



Clip into edge of Wide Panel unit to stay-stitching at all four Bag corners to aid in easing them in place along the Center Wall edges.



Again, push and place the Wide Panel Unit around your Bag Front so that the D-rings are "first-in."

the Gemini FlightBag (page 2)

Step 44 (cont.): Attaching Wide Panel Unit to Center Wall



Place LS of Wide Panel unit EST w/
Thin Panel unit (and Center Wall unit
underneath) aligning all edges &
notches.



Stitch a scant 1/4" from edges with
"zippered" side of Center Wall face
DOWN on machine bed as shown at
left.