

# the Gemini FlightBag

## Step 47: Attaching Bag Back to Wide Panel Unit



**Tip Box- \*ULTRA IMPORTANT\***  
If you're using locking zippers, (see prelim step A), then Wide Panel unit **MUST** be unzipped at least 6" at **ALL times** from this point forward & until your Bag is complete.

47) Retrieve Bag Back from step 21 & place it LSD on flat surface and flip Bag Front



Place Bag Front "Center Wall-side" UP onto ES of Bag Back aligning all edges & notches EST (and totally enclosing Bag Front INSIDE your Bag Back).

Clip remaining free Wide Panel edge to stay-stitching at all four corners to aid in easing them in place.



Stitch a scant 1/4" from edges with "zippered" side of Center Wall face DOWN on machine bed. Restitch entire seam for security.