



the Elsie K Baglet

Steps 51– Attaching Wide Panel unit



51) The main thing about step 51 is to place your Wide Panel unit over & around the Bag Fron with the D-ringed Panel 1 “first in”.

STOP! It's imperative that the wider “ring-tabbed” edge go DOWN & “first-in” so its aligned with the edges & notches of the Thin Panel unit, or your Bag will NOT hang straight!

See the Close Up below!

