



the Double Take

StudioKat Designs, Inc.

Steps 24-25: Attaching 1st Pouch in lining to Bag Back

Phone: 866/409-8634

Email: info@studiokatdesigns.com



Step 24– First things first, let's pin then stitch the 1st Pouch lining in place RSD on WS of Zipper, BUT... RST with Bag Back.



Step 25– Now let's align the triple notches of your Pouch in lining with those of Wall in lining. Pin in place so the raw edges are concealed (*stay-stitching of Wall can be visible*).



Step 25– Continue pinning the pressed under bottom edge of Pouch in lining to Wall in lining.



Step 25– Now for the stitching.

These 3 pictures (above and at right) are further evidence that this stitching need not be pretty or perfect.

As you can see (at bottom right) even after all the stitching is accomplished, the back stitching on the Wall is still visible and unconcealed. But this doesn't bother me because this black stitching will be totally imperceptible once this pouch is completed & turned RSO!

