



the Easy Go Wallet

Step 28+30-31

StudioKat Designs, Inc.

Phone: 866/409-8634

Email: info@studiokatdesigns.com

Adding the Wallet Floor



28) Reach under zippers now and pull zipper pulls OUT as far as possible beyond side edge of Wallet. Place a pin below each zipperhead to secure this placement then stitch across zipper teeth ~1/4" below bottom edge of zipperhead using a zipperfoot. Reinforce this stitching & trim away zipperends ~1" below this stitching.



28 cont) *This stitching does NOT need to extend out to side edges of zipper. It only needs to extend ~1/4" on either side of the zipper teeth themselves.*

Please note: this stitching WILL be visible on underside of Wallet.



30) Center & align Floor WSD DOWN over cut zippered ends in center of Wallet interior. (Floor should cover side edges & zipper ends completely). Pin place to secure placement

31) Using a zipperfoot, carefully topstitch close to edges around perimeter of Floor thru ALL layers.

(Please note: This is important stitching & WILL BE visible on the outside of your Wallet). Set Wallet aside for step 45.