



StudioKat Designs, Inc.

Phone: 336/416-1799

Email: info@studiokatdesigns.com

the Cignet Phone Pal

Step 29- Placing Wall Unit



29) Retrieve Bag Front from step 22. Align Wall unit RST w/Bag Front exterior aligning bottom triple notches & securing them w/a pin.

Next, "snug" both top corners of Wall just UNDER the Phone Pouch fabric strip & pin to secure both placements.

Finally, align side single notches then ease all edges in place. Stitch a full 1/4" from edges around Wall unit thru ALL layers.

Restitch for security & set Bag Front aside for step 33.

Here's a closeup!

