

Bangle Buddie- Attaching Center unit to Bag Front - Step 21



21) Retrieve Center unit from step 8. With one side of Center unit facing DOWN on flat surface (YOU choose which side, the elastic slots side OR Mesh Pocket side), place Panel/Base LST w/Center unit edges first aligning triple notches on Base, then matching all other notches & edges.

You'll be stitching a scant 1/4" from raw edges w/the Center unit facing DOWN on the machine bed.