Bangle Buddie- Attaching Bag Back - Step 41



Retrieve Bag Front from step 38. Place it EST with Bag Back (Mesh side \underline{or} elasticized side of Center unit will be facing OUT) by first aligning triple notches along Base edge, then ALL other notches & edges.



Using a zipper foot in this step and thru step 43, stitch in place a FULL 1/4" from edges with <u>Bag Back LSD</u> on machine bed. Restitch for security. Clip off notches & even up the edges.

CAUTION!
Your ENTIRE bag will
now be INSIDE-OUT!
Please take note of
zipper warning in the
Tip Box below step 38!!