

# The Cosmo Convertible

Steps 21-24

## “Separating Zipper Placement”

21) Place a pin exactly 1 1/4" away from each side seam. (FOUR placements)



23) Place pressed zipper top edge RST along purse opening. The top metal zipper stop should be placed right on the pin placement as shown above.

23) Continue pinning zipper RST to bag opening til you get to the 1 1/4" pin placement on opposite Bag corner, after which you'll want to bend your zipper tail DOWN. Pin it in place so it wont get sewed into your 1/4 seamage.



24) Pin other zipper piece in place and stitch 1/4" from raw edges. RESTITCH entire area for security. It should look like this when you're done.