

## Go-Go Compact- Adding Exterior Pouch Unit- Step 46a- 48

46a) Place Flap unit  
"pouch-side" UP on TOP  
of Front Lining side of  
Bag exterior.



47a) I included this picture to show you how I secure the folds of the bias tape with pins (as well as the "poofy-ness" of the Pouch PRIOR to flipping it ESD for stitching. This goes a long in preventing the bias tape from getting folded-over into my stitching path without my knowing it.



48) Using fabric ties, pull zipperhead out from under Floor as far as possible to side edge of Bag. Place a pin below zipperhead to secure placement then **hand-stitch across zipper teeth** as close as possible to base of zipperhead. (either thru or under the Bag Floor fabric.)

**(Please note: We recommend handstitching this area because machine stitching WILL be visible on your Bag exterior.)**