

Go-Go Compact- Placing & Stitching Mag Snaps in Place - Steps A1- A3

A1- Carefully cut out the area WITHIN mag snap circles for the following pattern pieces:

Slip Pocket in Fleece- #9a

Pouch Pocket in Foam- #11a

Tab- #13

Flap- #12

Now cut out these pieces as directed, then place them on a flat surface (w/fusible-side UP)

Please note that your foam probably doesn't have a fusible side.

Next, replace each pattern piece on it (aligning all outside edges), and mark along the edges within the cutout areas to transfer the snap placement to the fleece (or foam).



A2-A3- Separate each magnet pair and mark them so they can remain a matched set.



The 1st magnet set will be sewn onto your Flap (in fleece) & your Pouch Pocket (in foam). The set set will be sewn onto your Tab & Slip Pocket (both in fleece).

Place ALL magnet pieces **MAGNETIC-side UP** onto each item so that the magnet completely covers the marks made in step A1. Pin in place to secure.



IMPORTANT--- Clip off lower two plastic corners of Tab magnet, then stitch magnet in place close to plastic edges of magnets on ALL 4 items. Reinforce stitching.

Follow instructions presented in steps B3, C5, C6 and C7 to either stitch or fuse these items to your fabric pieces.

Please note that both the Slip Pocket in fleece and Pouch Pocket in foam do NOT completely cover the WS of fabric. This is intentional.

