



# The Side Slinger

Steps J1-J4— Marking & Placing the Magnetic Snaps



Carefully cut out the area WITHIN the mag snap circle indicated on pattern piece for Closure(#7) and Pocket 3(#6). Replace pattern piece on fusible side of interfacing & mark along inside of cutout circle.



Here's how it should look. Separate mag snap pieces and place one piece **MAGNETIC SIDE UP** within the outlined area on **FUSIBLE** side of interfacing.



Secure placement w/pins.



Stitch in place close to all four plastic edges. Be sure to reinforce this stitching. Now place & stitch remaining magsnap piece to fusible side of Pocket 3 interfacing in the same way.



Fuse interfacing to WS of Closure in contrast and Pocket 3 in exterior. **DON'T FORGET** to test these two items to make sure that the magnet pieces snap together strongly. If they don't, **STOP NOW** and find out why!