



the Tandem DayPack

Step 12

Attaching Bag Front to Bag Wall

StudioKat Designs, Inc.

Phone: 866/409-8634

Email: info@studiokatdesigns.com



12a) Retrieve Bag Front from step 10. Open zipper completely then place Bag Front LSD on Wall unit, first centering middle dart on bottom edge of Pouch w/double notch on bottom edge of Wall, then continue aligning all other notches & edges.

It's SO much easier to accomplish this stitching by opening the Pouch zipper completely and actually pushing the Flap INSIDE the Pouch (as seen at left).

12b) Stitch in place a scant 1/4" from edges around entire perimeter. Set Bag Front aside for step 17.

I strongly recommend placing this unit "Wall-side DOWN" on the machine bed (as shown at right) for this procedure to avoid having to contend & fight with the bulkiness of the Pouch while stitching.



Here's an overhead look at how this unit looks with the Flap stuffed Inside of the Pouch.

Trim the Zip Extenders even with Pouch side edges and you're all set to move on to step 13.