

the AeroSling

Steps 14: Stitching Front B lining in place

14a) Flip pressed edge of Front B lining UP onto the zipper seam created in step 13.

14b) (Make sure this lining *COVERS* the step 13 stitching.) Pin in place then stitch close to fabric edge.



I recommend pinning this area in place on the LS of Bag Front, (as you see above), BUT ... stitching it in place w/LS face down on machine bed, (as you see at left) to get a better topstitched look.

I find that if I stitch SLOW, I can avoid those pins as I go, but DO check the LS of this seam afterwards, to make sure the entire pressed edge of Front B lining was caught in this stitching.

Alternatively, this area can be handstitched.