



the Elsie K Baglet

Step 50 – Attaching Bag Front to Center Wall unit



50a) Clip to stay-stitching at all four corners of Thin Panel. Stitch a scant 1/4" from edges with "wallet-side" of Center Wall face DOWN on machine bed.



Openings for both CC Slots should be:
on the SAME side of the bag
(this particular sample is set up for a person who likes to carry their bag primarily on their left hip.)



50b) Stitch a scant 1/4" from edges with "wallet-side" of Center Wall face DOWN on machine bed.

As you can see, for this step I still think it helps to open this zipper completely.