

the High Seas Convertible

Steps 42-43

Anchoring the Top Band

StudioKat Designs, Inc.

Phone: 866/409-8634

Email: info@studiokatdesigns.com



42a) Pull Top Band UP pushing D-ring within DOWN as close as possible to Zip Panel seam edge. Pin in place.

42b) Open Bag to stitch as close as possible to D-ring edge enclosed within Top Band. Restitch for security as this is a weight bearing seam.



DO keep the top edge of your D-ring pushed DOWN & away from the moving machine parts during this process.

43) Now anchor folded edge of Top Band flat against Bag Back to secure its placement. Stitch close to the folded Top Band bottom edge. (this stitching may be somewhat visible inside Bag.)