

Packlets- Adding Bias Tape to Panel/Base seam - Steps 22-23



There's really nothing about bias tape to fear!


I know there's some bias tape links & info included on the bottom of page 2, but I thought I would include these pictures so you could see the way I think its easiest to apply bias tape to a Packlets!

Retrieve a bias tape strip from step D. Fold over the first 3/4" diagonally (WST) then begin pinning it in place RST along the long Base edges on Bag Face in LS of unit aligning raw edges.



Continue pinning around entire circumference of Bag Face.

I've included this picture so that you can see how I handle the bias taped corners. First off--- don't forget to give the tape a tug before each pinning and along those lines.... Use LOTS of pins. Secondly, you can keep the corner folds in line by including them in the pinnings as well! →



To finish,,overlap the bias tape tail ~3/4" over onto the diagonally folded end..

Here's a closeup of the bias tape tail overlapped on the diagonal starting point.



Clip off excess bias tape tail then flip unit over with **Bag Face LS DOWN on machine bed.** Stitch a **scant 1/4"** from edges.

I've included this picture because it clearly shows you that this stitching needs to be INSIDE of the step 21 seam stitching.